
SPT 40/60/90


INSTALLATION/MAINTENANCE INSTRUCTIONS - SUSPENDED








CAUTION! Make sure that the luminaire is always disconnected from mains during installation or maintenance work.





SPT 40/60/90

INSTALLATION/MAINTENANCE INSTRUCTIONS - SUSPENDED











Wiring Diagrams










DALI Dimming



1-10V Dimming

